



# QUICK-FIT INSTALLATION GUIDE

## Rear Wheel Bag



PRODUCT CODE:  
RWB

# Congratulations on your purchase of an MSA 4X4 quality Rear Wheel Bag!

## Fitting instructions:

1. Hold bag against spare wheel and position straps behind wheel. The straps cross over (See image on opposite page), and attach to the diagonal clips underneath the Rear Wheel Bag.
2. Unbuckle “Anti-Drop Strap” and pass under Spare Wheel Mount and back up to top of Rear Wheel Bag and re-attach to buckle.
3. Ensure bag is placed right at the top of spare wheel and firmly tension Anti Drop Strap. Firmly tension diagonal straps.
4. When both diagonal straps are tensioned, feed strap back through safety tri-slide clip.

Designed & Distributed by  
MSA 4X4 Accessories  
43 Harrington Street  
Arundel, Gold Coast  
QLD 4214 Australia  
Ph: 07 5594 6664  
[www.msa4x4.com.au](http://www.msa4x4.com.au)  
ABN: 50 150 429 566



Please refer to our website  
for lifetime guarantee full  
terms and conditions