



# QUICK-FIT INSTALLATION GUIDE

## Water Bra



PRODUCT CODE:  
WBL

# Congratulations on your purchase of an MSA 4X4 quality Water Bra!

## Fitting instructions:

1. Remove Water Bra from packaging and lay out to get orientation correct. Pouch on front of Water Bra goes to the top and holes for recovery straps go to the bottom.
2. Place Water Bra over Bullbar and position so that it is centered. If your vehicle does not have a Bullbar, you may need another person to hold the Water Bra in place.
3. Now run the side straps up and around your wing mirrors and back down to the quick release buckle and attach. Depending on the type of vehicle and/or size of your Bullbar, you may have to stretch the straps to reach. There is an elastic shock cord that runs around the whole Water Bra and through the straps. This shock cord is very strong and it may take some effort to stretch.
4. Once fitted and straps attached, adjust if necessary to make sure Water Bra is fitted over your Bullbar or the front of your vehicle.
5. Prior to your water crossing, recovery straps can be attached and stowed in the pouch on the front of the Water Bra for easy access.
6. Once water crossing is completed, remove the Water Bra. Do not drive on the road with Water Bra fitted as this will restrict air flow to your engine and will cause overheating

Designed & Distributed by  
MSA 4X4 Accessories  
43 Harrington Street  
Arundel, Gold Coast  
QLD 4214 Australia  
Ph: 07 5594 6664  
[www.msa4x4.com.au](http://www.msa4x4.com.au)  
ABN: 50 150 429 566



Please refer to our website  
for lifetime guarantee full  
terms and conditions